TAKE OFF





Open clip () and take the baby out

RELAX - when seated





Open clip (a) and give the baby more space

M-POSITION



It is advised by specialists to carry the baby in the ergonomic M-POSITION

Baby's bottom is lower than the spread upper legs, creating a kind of M-shape

TIGHTEN STRAP



Some users wear the sling too loose and too low

Our advice is (see step 12 of the instruction inside):

MAKE SURE YOU CARRY YOUR BABY HIGH AND TIGHT

NURSING COVER



Turn the sling so you can reach the clip on the back



'Lift' the clip thereby lowering the sling until baby's head is at breast height



Onen clin (




Gently pull the fabric up so you can feed discreetly



Feed the baby

100% cotton





Designed by Minimonkey | Amsterdam Modelnr.300108

SAFETY read before use

IMPORTANT! KEEP FOR FUTURE REFERENCE

WARNINGS

- Constantly monitor your child and ensure the mouth and nose are unobstructed.
- For pre-term, low birthweight babies and children with medical conditions, seek advice from a health professional before using this product.
- Ensure your child's chin is not resting on its chest as its breathing may be restricted which could lead to suffocation.
- To prevent hazards from falling ensure that your child is securely positioned in the sling.

Maximum carry weight 15kg • Intended for only 1 child • Be aware of hazards in the domestic environment e.g. heat sources, spilling of hot drinks • Your movement and the child's movement may affect your balance • Take care when bending and leaning forwards or sideways • The sling is not suitable for use during sporting activities e.g. running, cycling, swimming and skiing • Be aware of the increased risk of your child falling out of the sling as it becomes more active • Regular inspection of the sling for any signs of wear and damage • Keep this sling away from children when it is not in use



• Never leave baby unattended in hammock







INSTRUCTIONS SLING UNLIMITED



TIPS

WATCH INSTRUCTION VIDEOS ON OUR WEBSITE BEFORE USE

- practice with a doll and in front of mirror
- practice when baby is relaxed and not hungry
- if baby cries after you've put him in the sling, rock the baby a little
- give vourself and the baby some time to practice and to get used to the sling




The older the baby. the more you carry him on your hip



3 months+

9 months+


PREPARATION M-POSITION



Put sling on, cushion on shoulder. Sling can also be carried on the other shoulder



Slide (towards the sling (for newborn slide to the max)



Make a loop by fastening clip B into clip A

BABY IN THE SLING M-POSITION




Put one leg through loop (the baby is now secured)



Turn sling so that the logo (reference point) on the outer edge is positioned in the MIDDLE of the baby



Lower baby with spread legs in sling. Ensure baby's bottom is lower then upper legs - M-POSITION





CAREFULLY pull up fabric, tighten it around baby's back and neck (to support head) - for newborn pull up midway to the ears

* logo in the middle of the back of the baby




Attach clip (to clip ()




Fold the fabric TIGHTLY under the side and the bottom



Push the bottom up and pull the strap **TIGHT** so that the baby's head rests above your chest



Hold the lower legs and tilt them towards you and upwards, so that the baby relaxes and baby's back is round



Turn the sling so that 🝪 is just below your armpit and the top edge is straight





The sling is used correctly if (steps referring to instruction):

- (a) cushion flat on shoulder (step 1,11)
- (b) head above your chest (step 12)
- (c) head supported (step 2,7,8,11,12)
- d sling is aligned + logo in the middle (step 5,7,11)
- (e) fabric tightly around baby's back (step 6,7,9)
- (f) baby in M-position (step 6,10)
- **g** side just under armpit (step 11,12)
- (h) baby secured (step 3,4)